

Revised - 5/11/23

## Tensioner Adjustment Instructions

### Tools needed:

- Needle Nose Pliers
- $\frac{3}{8}$  Wrench
- $\frac{7}{16}$  Socket
- Electric or Battery Powered Drill

1. Using the  $\frac{3}{8}$  Wrench and  $\frac{7}{16}$  socket remove the plastic cover from the tensioner and set to the side for reassembly
2. Insert the needle nose pliers into the roller pin side of the axle
3. Turn the axle clockwise to loosen the cotter pin.
4. Remove the cotter pin from the opposite side of the axle. (Do not let go of pliers. The tension will release..)
5. Rotate the axel clockwise to increase the tension or counterclockwise to decrease the tension.
6. Ensure the rubber stopper is touching the roller.
7. Reinsert the cotter pin.
8. Place the cover back on the tensioner and tighten the hardware.

