



# International Adapter Bracket

## Installation Instructions

Item # EZCIAB | The **EZ Claw Line Saver International Adapter Bracket** designed for International day cab semi tractors with L-channel mounts.

### **International Adapter Kit includes:**

- (1) International Adapter Bracket
- (2) 3/8" M Hardware Kit

### **Recommended tools for installation:**

- (1) Drill
- (1) 9/16" Socket
- (1) 9/16" Wrench



# Installation Instructions

## Note:

This product is recommended for International day cabs with an air fairing mounting plate. The EZ Claw International Adapter Bracket (EZCIAB) is a mounting option that when assembled with the Versa Mount Short Bracket (EZCVMBS) bolts directly to factory-installed hardware without drilling or rivet nuts.

**1**

**FPO in-use to come**

### Remove Existing Bolts.

Remove bolts and nuts from the factory-installed air fairing mounting plate.

**2**

**FPO in-use to come**

### Install Bracket.

Place the International Adapter Bracket (EZCIAB) over the existing holes and threaded studs; then reinstall mounting hardware.

**3**

**FPO in-use to come**

### Tighten Assembly.

Tighten all hardware to secure the bracket and fairing (if applicable).

**4**

**FPO in-use to come**

### Install Versa Mount Short.

Using the provided hardware, mount the EZ Claw Versa Mount Short (EZCVMBS) to the face of the bracket.

**5**

**FPO in-use to come**

### Install Line Saver.

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the Line Saver.

**6**

**FPO in-use to come**

### Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.