



M2 Mount Bracket

Installation Instructions

Item # EZCM2B | The **EZ Claw M2 Mount Bracket** is designed for trucks with a short wheel base and minimal clearance between the tractor and the trailer.

Kit includes:

- (1) M2 Bracket
- (1) 3/8" Hardware Kit

Recommended Tools for Installation:

- (1) Drill
- (1) 1/4" Drill Bit
- (1) 3/8" Drill Bit
- (1) Permanent Marker or Center Punch
- (1) 9/16" Socket
- (1) 9/16" Wrench



Installation Instructions

Note:

The M2 Bracket is a top mount bracket designed for use on trucks with a short wheel base and minimal clearance between the tractor and the trailer. A perfect solution for urban food service companies that must utilize shorter wheelbase trucks for tight turns and small parking lots with reefer units on the trailers.

1

FPO in-use to come

Mark Hole Location.

Hold the mounting bracket on top of the factory-installed air fairing bracket on the driver side. Mark both holes.

2

FPO in-use to come

Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into roof of truck, insulation, wires, etc).

3

FPO in-use to come

Enlarge Pilot Holes.

Drill out the pilot hole using a 3/8" drill bit.

4

FPO in-use to come

Mount Bracket.

Mount the EZ Claw M2 Bracket (EZCM2B) using the supplied mounting hardware.

5

FPO in-use to come

Install Line Saver.

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the line saver.

6

FPO in-use to come

Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.