

**FPO in-use to come**

# EZ Claw Side Mount Bracket

## Installation Instructions

Item # EZCSMB | The **EZ Claw Side Mount Bracket** is intended to mount the Line Saver tensioner at the recommended 45-degree angle on the side of toolboxes or other structures.

### **Kit Includes:**

- (1) Side Mount Bracket
- (1) 5/16" Hardware Kit

### **Recommended Tools for installation:**

- (1) Battery Powered Drill
- (1) 1/4" Drill Bit
- (1) 17/32" Drill Bit
- (1) Rivet Nut Tool (EZCRNIT)
- (1) 1/2" Socket
- (1) 9/16" Socket
- (1) 9/16" Open Ended Wrench
- (1) Permanent Marker or Center Punch



# Installation instructions

1

FP0 in-use to come

## Select Location.

Select location 5 1/2' to 6' above the catwalk.

2

FP0 in-use to come

## Mark Holes.

Hold the mounting bracket up to the location and mark all four mounting holes ensuring mount holes are oriented 90 degrees to the catwalk.

3

FP0 in-use to come

## Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into insulation, wires, etc).

4

FP0 in-use to come

## Enlarge Holes.

Drill out the pilot holes using a 17/32" drill bit.

5

FP0 in-use to come

## Install Rivet Nuts.

Install four rivet nuts using a rivet nut tool (EZCRNIT).

6

FP0 in-use to come

## Mount Bracket.

Mount the EZ Claw Side Mount Bracket using 5/16" flange bolts provided.

**7**

**FP0 in-use to come**

**Install Line Saver.**

Mount the EZ Claw Line Saver using the supplied 3/8" hardware kit.

**8**

**FP0 in-use to come**

**Attach Hose Assembly.**

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.