



Yard Truck Adapter Bracket

Installation Instructions

Item # EZCYTAB | The **EZ Claw Yard Truck Adapter Bracket** mounts above the cab on the side of the yard hostler and helps to keep the rear passage door free from tripping hazards.



Recommended Tools for Installation:

- (1) Battery Powered Impact Driver
- (1) 7/16" Socket
- (1) 1/2" Socket
- (1) 1/2" Open Ended Wrench
- (1) 9/16" Socket
- (1) 9/16" Open Ended Wrench

Kit Includes:

- (1) Yard Truck Adapter Bracket
- (1) 5/16" YTAB Hardware Kit

Installation Instructions

1



Remove Existing Hardware.

Remove the factory-installed 5/16" flange nut from the spotlight base (as shown), along with any other hardware on the light bracket that interferes with installation of the Yard Truck Adapter Bracket.

2



Wiring & Alignment.

Feed light wiring through the slot on the bottom of the Yard Truck Adapter Bracket and align three holes of the new bracket with corresponding holes on the factory-installed light bracket. Attach supplied 5/16" hardware (bolt/washers/lock nut) in top hole.

3



Spotlight Options.

Install additional supplied 5/16" hardware (bolt/washers/lock nut) in bottom two holes indicated by the red arrows above. If rear-facing spotlight was removed in Step 1, utilize the stud from the spotlight instead of the bolt supplied and re-install the spotlight.

4



Tighten Bracket.

Install EZ Claw Yard Truck Line Saver on Yard Truck Adapter bracket utilizing supplied 3/8" hardware.

5



Connect Lines.

Install 3-in-1 wrapped air and electric lines. Cut the spiral wrap in the approximate center of the of the lines and install the Hose & Cable Block (EZCHCH38) on hoses.

6



Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block, attach the EZ Claw Line Saver cable to the hose assembly.