



M2 Mount Bracket

Installation Instructions

Item # EZCM2B | The **EZ Claw M2 Mount Bracket** is designed for trucks with a short wheel base and minimal clearance between the tractor and the trailer.

Kit includes:

- (1) M2 Bracket
- (1) 3/8" Hardware Kit

Recommended Tools for Installation:

- (1) Drill
- (1) 1/4" Drill Bit
- (1) 3/8" Drill Bit
- (1) Permanent Marker or Center Punch
- (1) 9/16" Socket
- (1) 9/16" Wrench



Installation Instructions

Note:

The M2 Bracket is a top mount bracket designed for use on trucks with a short wheel base and minimal clearance between the tractor and the trailer. A perfect solution for urban food service companies that must utilize shorter wheelbase trucks for tight turns and small parking lots with reefer units on the trailers.

1. Mark Hole Location.

Hold the mounting bracket on top of the factory-installed air fairing bracket on the driver side. Mark both holes.

2. Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into roof of truck, insulation, wires, etc).

3. Enlarge Pilot Holes.

Drill out the pilot hole using a 3/8" drill bit.

4. Mount Bracket.

Mount the EZ Claw M2 Bracket (EZCM2B) using the supplied mounting hardware.

5. Install Line Saver.

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the line saver.

6. Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.