

EZ Claw M2 Adapter Bracket

Installation Instructions

Item #EZCM2AB | The **EZ Claw M2 Adapter Bracket** is for Freightliner M2 models without a factory-installed air fairing. Use with EZ Claw Versa Mount Bracket (EZCVMB) or EZ Claw Versa Mount Short Bracket (EZCVMBS).



Package Contents:

- (1) M2 Adapter Bracket
- (1) 5/16" Mounting Hardware Kit
- (2) 3/8" Mounting Hardware Kit N

Tools Needed for Assembly:

- (1) 1/4" Drill Bit
- (1) 17/32" Drill Bit
- (1) Rivet Nut Tool (EZCRNIT), Sold Separately
- (1) 1/2" Socket
- (1) 9/16" Socket
- (1) 9/16" Wrench
- (1) Permanent Marker or Center Punch

Installation Instructions

Note:

The M2 Adapter bracket (EZCM2AB) is used on Freightliner M2 model trucks without a factory-installed air fairing. Use with EZ Claw Versa Mount Bracket (EZCVMB) or EZ Claw Versa Mount Short Bracket (EZCVMBMS).

1. Determine Mounting Location.

Hold the mounting bracket, positioning the bottom leg in the recessed area around the rear window and the top leg on the roof of the cab. Mark the four mounting holes on the bracket with a marker or center punch.

2. Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into insulation, wires, etc).

3. Enlarge Holes.

Drill out the pilot holes using a 17/32" drill bit.

4. Install Rivet Nuts.

Install four rivet nuts using a rivet nut tool (EZCRNIT, sold separately).

5. Install Adapter.

Mount the EZ Claw M2 Adapter Bracket using the 5/16" flange bolts provided.

6. Mount Second Bracket.

Using the two 3/8" mounting hardware kits included, install the EZ Claw Versa Mount Bracket (EZCVMB) or EZ Claw Versa Mount Short Bracket (EZCVMBMS) directly to the face of the M2 Adapter Bracket (EZCM2AB).

7. Install Line Saver.

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the Line Saver.

8. Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.