

EZ Claw Side Mount Bracket

Item # EZCSMB | The **EZ Claw Side Mount Bracket** is intended to mount the Line Saver tensioner at the recommended 45-degree angle on the side of toolboxes or other structures.

Kit Includes:

- (1) Side Mount Bracket
- (1) 5/16" Hardware Kit

Recommended Tools for installation:

- (1) Battery Powered Drill
- (1) 1/4" Drill Bit
- (1) 17/32" Drill Bit
- (1) Rivet Nut Tool (EZCRNIT)
- (1) 1/2" Socket
- (1) 9/16" Socket
- (1) 9/16" Open Ended Wrench
- (1) Permanent Marker or Center Punch



Installation Instructions

1. Select Location.

Select location 5 1/2' to 6' above the catwalk.

2. Mark Holes.

Hold the mounting bracket up to the location and mark all four mounting holes ensuring mount holes are oriented 90 degrees to the catwalk.

3. Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into insulation, wires, etc).

4. Enlarge Holes.

Drill out the pilot holes using a 17/32" drill bit.

5. Install Rivet Nuts.

Install four rivet nuts using a rivet nut tool (EZCRNIT).

6. Mount Bracket.

Mount the EZ Claw Side Mount Bracket using 5/16" flange bolts provided.

7. Install Line Saver.

Mount the EZ Claw Line Saver using the supplied 3/8" hardware kit.

8. Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.