

Pivoting Center Post Mount Retrofit Kit

Installation Instructions

Item # EZC-SCPM-RETRO | The **EZ Claw** **Pivoting Center Post Mount Retrofit Kit** upgrades an existing Center Post Mount to the swiveling Center Post configuration. This retrofit improves performance and allows smoother movement of the EZ Claw Line Saver System.

Kit Includes:

- (1) Swivel Head Mount with mounting hardware
- (1) 3/8-16 x 1 GR8 Hex Flange Bolt

Recommended Tools for Installation:

- (1) Drill
- (1) Battery-Powered Impact Driver
- (1) Permanent Marker or Center Punch
- (1) 3/8" Drill Bit
- (1) 9/16" Socket
- (1) 9/16" Open End Wrench



Installation Instructions

1. Remove Existing Line Saver(s).

Unhook the lines from the EZ Claw Line Saver(s). Remove the Line Saver(s) from the current Universal Head Mount.

2. Remove Existing Head Mount.

Unbolt the Universal Head Mount from the top of the Center Post. Set all hardware aside.

3. Mark and Drill Front Mounting Hole.

Place the new Swivel Head on top of the Center Post. Mark the front hole location (approximately 1-7/16" down from the top of the Center Post and centered on the face). Remove the head. Drill the marked hole using a 3/8" drill bit.

4. Install Swivel Head Assembly.

Position the Swivel Head onto the Center Post. Install the 3/8-16 x 1 flange bolt through the Center Post and into the rivet nut. Install the two rear bolts and nuts. Once all hardware is installed, tighten securely.

5. Reinstall Line Saver(s).

Reinstall the EZ Claw Line Saver(s) onto the Swivel Head using the existing hardware. Ensure the cable exits from the top and routes over the stainless steel guide roller.

6. Attach Hose Assembly.

Use either: EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38). Attach the EZ Claw Line Saver cable to the hose assembly.