



# Top Mount Bracket

## Installation Instructions

Item # EZCTMB | The **EZ Claw Top Mount Bracket** can be used on the top of aluminum toolboxes or headache racks.

### Top Mount Kit includes:

- (1) Top Mount Bracket
- (1) 5/16" TMB Hardware Kit
- (1) 1/8" Rubber Gasket

### Recommended tools for installation:

- (1) Battery Powered Drill
- (1) 1/4" Drill Bit
- (1) 3/8" Drill Bit
- (1) 9/16" Socket
- (1) 9/16" Open Ended Wrench
- (1) Permanent Marker or Center Punch



# Installation Instructions

## Note:

The Top Mount Bracket can be used on the top of aluminum tool boxes or headache racks but is not recommended for use on the top of the cab. Use the EZ Claw Gasket (EZCGVMB) between the mounting bracket and the toolbox to aid in sealing the toolbox and to dampen any road vibration. Adequate reinforcement should be used inside the toolbox to ensure a secure mount.

## 1. Select Location.

Select a mounting location on top of the toolbox (favor driver side of the cab).

## 2. Mark Mounting Holes.

Hold the bracket in the selected position and mark all four mounting holes.

## 3. Drill Pilot Hole.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to drill into insulation, wires, etc).

## 4. Enlarge Pilot Holes.

Drill out the pilot hole using a 3/8" drill bit.

## 5. Line Up Gasket.

Align the gasket with holes.

## 6. Mount Bracket.

Using the provided nuts, bolts and washers, mount the bracket to the top of the toolbox.

## 7. Install Line Saver.

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the Line Saver.

## 8. Attach Hose Assembly.

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.