



LO-RES. NEED NEW PHOTO OR REPLACE

# EZ Claw PACCAR Adapter Bracket

## Installation Instructions

Item #EZCPAB | The **EZ Claw PACCAR**

**Adapter Bracket** The PACCAR Adapter Bracket (EZCPAB) is for use on Kenworth or Peterbilt trucks with three windows on the back of the cab. Use this adapter bracket in conjunction with the Versa Mount Bracket (EZCVMB) or Versa Mount Short Bracket (EZCVMSB).

### Package contents:

- (1) PACCAR Adapter Bracket
- (1) 5/16" Mounting Hardware Kit
- (2) 3/8" Mounting Hardware Kit

### Tools needed for assembly:

- |                      |                    |                                      |
|----------------------|--------------------|--------------------------------------|
| (1) Drill            | (1) Rivet Nut Tool | (1) 9/16" Wrench                     |
| (1) 1/4" Drill bit   | (1) 1/2" Socket    | (1) Permanent Marker or Center Punch |
| (1) 17/32" Drill bit | (1) 9/16" Socket   |                                      |



# Installation Instructions

1

FPO in-use to come

## Mark Hole Locations.

Hold the mounting bracket with the three legs facing the back of the cab. The third leg of the bracket should point down and be positioned at the top of the cab between the driver side rear window and the middle window. Mark all three mounting holes.

2

FPO in-use to come

## Drill Pilot Holes.

Using a 1/4" bit, carefully drill pilot holes in the center of each mark (being careful not to plunge into insulation, wires, etc).

3

FPO in-use to come

## Enlarge Holes.

Drill out the pilot holes using a 17/32" drill bit.

4

FPO in-use to come

## Install Rivet Nuts.

Install three rivet nuts using a rivet nut tool (EZCRNIT).

5

FPO in-use to come

## Install Adapter.

Mount the EZ Claw PACCAR Adapter Bracket using the 5/16" flange bolts provided.

6

FPO in-use to come

## Mount Versa Bracket.

Using the two 3/8" M Kits, install the EZ Claw Versa Mount Bracket (EZCVMB) or EZ Claw Versa Mount Short Bracket (EZCVMSB) directly to the face of the PACCAR Adapter Bracket.

**7**

**FPO in-use to come**

**Install Line Saver.**

Mount the EZ Claw Line Saver utilizing the 3/8" mounting hardware supplied with the Line Saver.

**8**

**FPO in-use to come**

**Attach Hose Assembly.**

Using an EZ Claw Sling (EZCS) or Hose & Cable Block (EZCHCH38), attach the EZ Claw Line Saver cable to the hose assembly.